


Instruction Manual



GSPCR 28-36

Drag Type Offset Disc Harrow Remote Control

 **BALDAN**

■ Presentation

We appreciate the preference and would like to congratulate you for excellent choice you just made, since you have acquired a product manufactured with **BALDAN**



IMPLEMENTOS AGRÍCOLAS S/A technology.

This manual will guide you through the procedures required since its acquisition until operational procedures of usage, safety and maintenance.

BALDAN assures that it has delivered this implement for resale in full and in perfect conditions.


Resale was responsible for the custody and maintenance during the period in its possession, and also for the assembly, retightening, lubrication and overhaul.

During the technical delivery, dealer should guide the user regarding maintenance, safety, their obligations in eventual technical assistance, strict compliance with the warranty term and reading the instructions manual.

Any technical assistance request while in warranty must be made to the dealer from whom you have purchased it.

We reiterate the need for a careful read of the warranty certificate and compliance of all items from this manual, because by doing so you will increase the life of your device.

Instruction Manual



GSPCR 28-36

Drag Type Offset Disc Harrow Remote Control

BALDAN IMPLEMENTOS AGRÍCOLAS S/A.
CNPJ: 52.311.347/0009-06
Insc. Est.: 441.016.953.110



Scan the QR Code on the identification plate of your device and access this Instruction Manual online.

 **BALDAN**

▪ Index

BALDAN WARRANTY	07
GENERAL INFORMATION	08
<i>To the owner</i>	<i>08</i>
SAFETY RULES.....	09-11
<i>To the operator.....</i>	<i>09</i>
SAFETY RULES.....	12
<i>PPE Equipment.....</i>	<i>12</i>
WARNINGS	13-14
COMPONENTS.....	15
<i>GSPCR - Drag Type Offset Disc Harrow Remote Control</i>	<i>15</i>
DIMENSIONS	16
<i>GSPCR 28 / 32 / 36 Discos</i>	<i>16</i>
SPECIFICATIONS	17
<i>GSPCR - Drag Type Offset Disc Harrow Remote Control</i>	<i>17</i>
ASSEMBLY	18-34
<i>Discs section assembly.....</i>	<i>18</i>
<i>Discs section assembly - GSPCR 28 discs</i>	<i>19</i>
<i>Discs section assembly - GSPCR 32 discs</i>	<i>20</i>
<i>Discs section assembly - GSPCR 36 discs</i>	<i>21</i>
<i>Assembly of the right main frame in te left main frame</i>	<i>22</i>
<i>Gangs assembly.....</i>	<i>23</i>
<i>Assembly of the gangs in the main frame</i>	<i>24</i>
<i>Assembly of the disc sections in the gangs</i>	<i>25</i>
<i>Scrappers Assembly.....</i>	<i>26</i>
<i>Wheel shaft support assembly</i>	<i>27</i>
<i>Assembly of the wheel axle support in the main frame</i>	<i>28</i>
<i>Wheels assembly</i>	<i>29</i>
<i>Hitch drawbar assembly.....</i>	<i>30</i>
<i>Hydraulic cylinder assembly on the hitch drawbar</i>	<i>31</i>
<i>Hydraulic cylinder assembly on the main frames.....</i>	<i>32</i>
<i>Signpost assembly</i>	<i>33</i>
HITCH.....	35
LEVELING	36-34
REGULATIONS	38
<i>Regulation for transportation - Part I</i>	<i>38</i>
<i>Regulation for transportation - Part II</i>	<i>39</i>
<i>Regulation for transportation - Part III</i>	<i>40</i>
<i>Adjustment of disc harrow opening</i>	<i>41</i>
<i>Working depth adjustment - Part I</i>	<i>42</i>

▪ Index

<i>Working depth adjustment - Part II</i>	<i>43</i>
<i>Adjustment of disc harrow displacement - Part I.....</i>	<i>44</i>
<i>Adjustment of disc harrow displacement - Part II.....</i>	<i>45</i>
<i>Recomendações para operação - Parte I</i>	<i>46</i>
<i>Recomendações para operação - Parte II</i>	<i>47</i>
<i>Direction of maneuvers</i>	<i>47</i>
<i>How to start harrowing.....</i>	<i>48</i>
<i>Harrow from the outside in.....</i>	<i>48</i>
<i>Harrow from the inside out.....</i>	<i>49</i>
<i>Blocks with contour lines</i>	<i>49</i>
CALCULATIONS.....	50
<i>Approximate hourly production.....</i>	<i>50</i>
MAINTENANCE	51
<i>Tire pressure.....</i>	<i>51</i>
<i>Lubrication.....</i>	<i>52</i>
<i>Greases and equivalents table</i>	<i>52</i>
<i>Lubricate every 24 hours of work.....</i>	<i>53</i>
<i>Disc section bearings adjustments</i>	<i>54</i>
<i>Bearing oil.....</i>	<i>54</i>
<i>Operational Maintenance</i>	<i>55</i>
<i>Care.....</i>	<i>56</i>
<i>General cleaning.....</i>	<i>56-57</i>
<i>Conservation of the harrow - Part I</i>	<i>57</i>
<i>Conservation of the harrow - Part II</i>	<i>57</i>
LIFTING.....	59
<i>Lifting points.....</i>	<i>59</i>
OPTIONAL	59
<i>Cutting Disc</i>	<i>59</i>
IDENTIFICATION.....	60

▪ **Baldan Warranty**

BALDAN IMPLEMENTOS AGRÍCOLAS S/A ensures the dealer normal performance of the implement for a period of six (6) months as of the delivery date on the retail invoice to the first final consumer.

During this period, **BALDAN** undertakes to repair defects in material and/or of manufacture of its liability, including labor, freight and other expenses of the dealer's liability.

In the warranty period, request and replacement of eventual defective parts shall be made to the dealer of the area, who will submit the faulty piece for **BALDAN** analysis.

When this procedure is not possible and the resolving capacity of the dealer is exhausted, the dealer will request the support of **BALDAN** Technical Assistance through a specific form distributed to dealers.

After analyzing the replaced items by **BALDAN** Technical Assistance, and concluding that it is not a warranty, then the dealer will be responsible for the costs related to the replacement; as well as material expenses, travel including accommodation and meals, accessories, lubricant used and other expenses arising from the call out to Technical Assistance, and **BALDAN** company is authorized to carry the respective invoice in the name of the resale.

Any repair carried out in the product within the dealer warranty deadline will only be authorized by **BALDAN** upon previous budget presentation describing parts and workforce to be executed.

The product is excluded from this term if it is repaired or modified by representatives not belonging to the **BALDAN** dealer network, as well as the application of non-genuine parts or components to the user's product.

This warranty is void where it is found that the defect or damage is caused by improper use of the product, failure to follow instructions or inexperience of the operator.

It is agreed that this warranty does not cover tires, polyethylene tanks, cardan shafts, hydraulic components, etc., which are equipment guaranteed by their manufacturers.

Manufacturing and/or material defects, object of this warranty term, will not constitute, under any circumstances, grounds for termination of a purchase agreement, or for indemnification of any nature.

BALDAN reserves the right to change and/or perfect the technical characteristics of its products, without previous notice, and without obligation to proceed in the same way with the products previously manufactured.

▪ General Information

• To the owner

BALDAN IMPLEMENTOS AGRÍCOLAS S/A is not responsible for any damaged caused by accident due to usage, transportation, or in the improper or incorrect transportation of its implement, whether by negligence and/or inexperience of any person.

Only people with complete knowledge of the tractor and the implement should carry their transportation and operation.

BALDAN is not responsible for any damaged caused in unpredictable or unrelated situations to the normal use of the implement.

The incorrect handling of this equipment may result in severe or fatal accidents. Before starting the equipment, carefully read the instructions contained in this manual. Make sure that the person responsible for the operation is instructed as the correct and safe handling. Also make sure that the operator has read and understood the instructions manual of the product.

ATTENTION

NR-31 - SAFETY AND HEALTH AT WORK IN AGRICULTURE, LIVESTOCK FORESTRY, FOREST EXPLORATION AND AQUACULTURE.

The purpose of this Regulatory Standard is to establish the precepts to be observed in the organization and in the work environment, in a manner compatible with the planning and development of agriculture, livestock, forestry and aquaculture activities with the safety and health and environment work environment.

MR. OWNER OR OPERATOR OF THE EQUIPMENT.
Read and carefully comply with provisions of NR-31.

For more information, refer to the site and read in full NR-31.
<http://portal.mte.gov.br/legislacao/normas-regulamentadoras-1.htm>

▪ Safety Rules

- To the operator



THIS SYMBOL INDICATES IMPORTANT SAFETY WARNING. IN THIS MANUAL, WHENEVER YOU FIND IT, READ THE FOLLOWING MESSAGE CAREFULLY AND PAY ATTENTION TO THE POSSIBILITY OF PERSONAL ACCIDENTS.



ATTENTION



Carefully read the instructions manual to learn about the recommended safety practices.



ATTENTION



Only start to operate the tractor when you are properly seated and with the seat belt locked.




ATTENTION



Do not transport people or equipment on the tractor.



ATTENTION



There are risks of severe injuries due to tipping when working in sloped terrains. Do not over speed.



ATTENTION



Do not work with the tractor if the front has insufficient ballast to the rear equipment. Should there be a trend to lift, add weights or ballasts to the front or the front wheels.



ATTENTION



Before performing any maintenance in your equipment, make sure it is properly stopped. Avoid being run over.



ATTENTION



Be careful when handling the GSPCR support leg, as there is a risk of accidents.

▪ Safety Rules

! ATTENTION FOLLOW ALL RECOMMENDATIONS, WARNINGS AND SAFE PRACTICES RECOMMENDED IN THIS MANUAL, UNDERSTAND THE IMPORTANCE OF YOUR SAFETY. ACCIDENTS MAY LEAD TO DISABILITY OR INCLUDING DEATH. REMEMBER, ACCIDENTS CAN BE AVOIDED!

! ATTENTION



Do not make adjustments with the GSPCR in operation. When doing any service on the GSPCR, turn off the tractor first. Use appropriate tools.


! ATTENTION

25
KM/H

15
MPH

When transporting the GSPCR, do not exceed the speed of 25Km/h or 15 MPH, avoiding risks of damages and accidents.

! ATTENTION



Remove the ignition key before performing any maintenance on the GSPCR. Protect yourself from possible injury or death caused by an unforeseen GSPCR start up. If the GSPCR is not properly engaged, do not start the tractor.

! ATTENTION



When looking for possible leaks in hoses, use a cardboard or wood, never use your hands. Avoid fluid incision into the skin.

! ATTENTION

12
KM/H

7
MPH

When working with the GSPCR, do not exceed the speed of 12Km/h or 7 MPH, avoiding risk of damages and accidents.

! ATTENTION



Hydraulic oil works under pressure and may cause serious injuries if there are any leaks.

Periodically check hoses for conservation. If there are any sign of leakage, replace them immediately. Before connecting or disconnecting hydraulic hoses, relief system pressure by activating the command with the tractor power switched off.

▪ Safety Rules

ATTENTION



Always maintain places of access and work free of residues such as oil or grease to prevent accidents.

ATTENTION



Avoid heating parts near the fluid lines. Heating may generate fragility in the material, rupture and exit of the pressurized fluid, causing burns and injuries

ATTENTION



Never weld the tire-mounted wheel, the heat may cause increased air pressure and cause the tire to burst.


When filling the tire, position yourself besides the tire, never in front of it. To inflate a tire, always use a containment device (inflation cage).

ATTENTION



Before commencing work or transportation to GSPCR, check for any nearby persons or obstructions.

ATTENTION



Keep the joint area free while the GSPCR is in operation. In closed curves, prevent tractor wheels from touching the head.

ATTENTION



Always stay away from the active elements of the GSPCR (discs), they are sharp and can cause accidents. When performing any service in the discs, wear safety gloves.

ATTENTION



Disposing of waste improperly affects the environment and the environment, as it will pollute rivers, canals or the soil. Inform yourself about the proper way of recycling or disposing residues.

PROTECT THE ENVIRONMENT!

▪ Safety Rules

• PPE Equipment

! ATTENTION | DO NOT WORK WITH THE GSPCR WITHOUT WEARING PPE (SAFETY EQUIPMENT). IGNORING THIS WARNING MAY CAUSE DAMAGES TO HEALTH, SEVERE ACCIDENTS OR DEATH.

When performing certain procedures with the **GSPCR**, wear the following Safety Equipment (PPE):




















! IMPORTANT

Safety practice must be performed in all stages of working with the GSPCR, thus avoiding accidents such as impact of objects, fall, noise, cuts and ergonomics, in other words, the person responsible for operating the GSPCR is subject to internal and external bodily damage.















🔍 OBSERVATION | All PPEs (Safety Equipment) should have certificate of authenticity.



▪ Warnings

-  When operating with the GSPCR, do not let people stay close or on it.
-  When performing any maintenance service, use PPEs equipment.
-  Before connecting or disconnecting hydraulic hoses, relief the system pressure by activating the command with the tractor power switched off.
-  Periodically check the conservation status of the hydraulic hoses. If there are indications of oil leakage, replace the hose immediately, because the oil works under high pressure and may cause serious accidents.
-  Do not wear loose clothing, as they may get caught in the GSPCR.
-  When operating the tractor engine, be properly seated in the operator's seat and be aware of the full knowledge of the correct and safe handling of both the tractor and the GSPCR. Always put the gear shift in neutral position, unplug the power take-off gear switch and place the hydraulic controls in neutral position.
-  Do not start the motor in a closed environment or with no proper ventilation since the exhaust gases are harmful to health.
-  When maneuvering the tractor to the GSPCR hitch, make sure you have adequate clearance and that there are no people too close, always maneuver at idle and be prepared to brake in an emergency.
-  Do not make adjustments with the GSPCR in operation.
-  When working in sloped terrains, proceed with precautions, always trying to maintain the required stability. In case of imbalance, reduce acceleration, turn the wheels to the slope side of the terrain and never lift the GSPCR.
-  Always conduct the tractor in speeds compatible to the safety, especially during works in bumpy lands or slopes, keep the tractor always engaged.
-  When driving the tractor in highways, keep the brake pedals interconnected.
-  Do not work with the tractor with light rear. If the rear has a tendency to lift, add more weights on the rear wheels.
-  When leaving the tractor, put the gear lever in neutral position and apply the parking brake. Never leave the GSPCR on the tractor in the raised position of the hydraulic system.
-  The GSPCR must be turned off before any maintenance work.
-  Do not travel on highways especially at night. Use warning signs throughout the course
-  If you need to travel with the GSPCR on highways, consult traffic authorities.

▪ Warnings

-  The GSPCR must not be operated by untrained people, i.e. people who do not know to properly operate it.
-  Do not transport or work with the GSPCR near obstacles, rivers or streams.
-  The transportation of people on self-propelled machines and implements is forbidden.
-  Changes to the original GSPCR characteristics are not allowed, as they may alter the safety, operation and life of the GSPCR.
-  Read all safety information contained in this manual and the GSPCR carefully.
-  Read or explain all the procedures of this manual to the operator who cannot read.
-  Always check that the GSPCR is in perfect conditions of use. In the event of any irregularity that may interfere with the operation of the GSPCR, ensure proper maintenance before any work or transportation.
-  Maintenance and especially inspection in GSPCR risk areas should be done only by a qualified or qualified worker, observing all safety guidelines. Before starting maintenance, disconnect all GSPCR drive systems.
-  Periodically check all components of the GSPCR before using it.
-  Due to the equipment used and work conditions on field or in maintenance areas, precautions are required. Baldan has no direct control over precautions, so it is the owner's responsibility to implement safety procedures while working with GSPCR.
-  Check the recommended minimum tractor power for each GSPCR model. Only use tractor with power and ballast compatible with the load and topography of the terrain.
-  When transporting the GSPCR, travel at speeds compatible with the terrain and never exceed 16 km/h, as this reduces maintenance and consequently increases the life of the GSPCR.
-  Alcoholic beverage or some medications may cause loss of reflexes and change the operator's physical conditions. Therefore, never operate this GSPCR under the influence of these substances.
-  Read or explain all the procedures of this manual to the operator who cannot read.


In case of doubts, refer to Post-Sales.

Telephone: 0800-152577 / E-mail: posvenda@baldan.com.br

▪ Components


• GSPCR - Drag Type Offset Disc Harrow Remote Control

- | | |
|-------------------------------------|------------------------------------|
| 1. Right main frame | 9. Stabilizer rod |
| 2. Left main frame | 10. Scraper |
| 3. Front gang | 11. Tyre |
| 4. Rear gang | 12. Wheel shaft support |
| 5. Hitch drawbar | 13. Disc |
| 6. Lifting Support | 14. Signpost |
| 7. Hoses support | 15. Cylinder of wheel articulation |
| 8. Cylinder of drawbar articulation | 16. Hydraulic hoses |



▪ Dimensions

• GSPCR 28 / 32 / 36 Discos



Model	No. of Discs	Measure A (mm)	Measure B (mm)	Measure C (mm)	Measure D (mm)
GSPCR	28	5728	9550	320	1865
GSPCR	32	6430	9830	320	1865
GSPCR	36	7240	10040	320	1865

■ Specifications

• GSPCR - Drag Type Offset Disc Harrow Remote Control

Model	No. of Discs	Width of Job (mm)	Diameter of the Discs (ø)	Discs Concave (mm)	Diameter Axis (ø)
GSPCR	28	5605	32" - 34" - 36"	12	2.1/2"
	32	6377	32" - 34" - 36"	12	2.1/2"
	36	7147	32" - 34" - 36"	12	2.1/2"

Modelo	No. of Discs	Weight Approximate (Kg)			Wattage Tractor (HP)	Tires	
		32"	34"	36"		Quantity	Model
GSPCR	28	8070	8225	8435	420 à 470	04	400x60
	32	9540	9720	9960	480 à 535	04	400x60
	36	10.030	10.230	10.500	540 à 560	04	400x60

Disc spacing 430 mm

Working depth 200 - 320 mm

Recommended maximum working speed 12km/h

Recommended maximum transport speed 25km/h

Baldan reserves the right to change and or improve the technical characteristics of its products, without prior notice, and without obligation to do so with previously manufactured products.

Technical specifications are approximate and reported under normal working conditions.

EXPECTED USE OF GSPCR

- The **GSPCR** was developed for soil preparation work in large areas and in various types of terrain.
- The **GSPCR** must be driven and operated only by a properly instructed operator.

NOT ALLOWED USE OF GSPCR

- To avoid damage, serious accident or death, DO NOT transport people over any part of the **GSPCR**.
- It is NOT allowed to use the **GSPCR** to attach, tow or push other implements or accessories.
- The **GSPCR** must NOT be used by an inexperienced operator who does not know all the driving, command and operation techniques.

▪ Assembly

GSPCR leaves the factory dismantled. To assemble it, follow the instructions below:

⚠ The **GSPCR** Assembly must be done by resale, through trained, qualified and qualified people for this work.

⚠ Before starting the **GSPCR** Assembly, look for an ideal location, where it will facilitate the identification of the parts and the assembly thereof.


⚠ Do not wear loose clothing, as they may get caught in the **GSPCR**.

▪ Assembly

• Discs section assembly

When starting the **GSPCR** Assembly, always start with the disk set for this, proceed as follows:

- 01** - Place on the shaft (1) the concave thrust washer (2), flat washer (3), lock (4), nut (5), fixing it with the pressure washer (6) and the screw (7).
- 02** - Then place the disc (8), bearing (9), another disc (8), separator spool (10) on the shaft (1), and so on.
- 03** - When the set is complete with all the discs, bearings, separating reels, place the convex thrust washer (11), flat washer (12), lock (13), nut (14), tightening it with the key until it is firm the set.
- 04** - Once this is done, put on the disc set and tighten the nut (14) with impacts. When you are almost getting maximum tightness, adjust the lock (13) with the convex washer (11), always tightening the nut until the drilling coincides, fix it with the pressure washer (15) and the screw (16).




ATTENTION Check the right side of the separator spools and bearings, according to the concavity of the discs.

▪ Assembly

• Discs section assembly - GSPCR 28 discs


Check below the Assembly of the **GSPCR 28** discs sections.



▪ Assembly

• Discs section assembly - GSPCR 36 discs

Check below the Assembly of the **GSPCR 36** discs sections.




▪ Assembly

• Assembly of the right main frame in te left main frame

Start the **GSPCR** Assembly by the main frame. For this, proceed as follows:

- 01** - Couple the right main frame (1) with the left main frame (2), fixing using the screws (3), lock washers (4) and nuts (5).




Fix the main frames with the screws (3), lock washers (4) and nuts (5) at all other points "A".

▪ Assembly

• Gangs assembly

After coupling the main frames, attach the gangs. For this, proceed as follows:

- 01** - Place the front and rear gangs in a flat, clean place.
- 02** - Then, attach the right front gang (1) to the left front gang (2) by fixing using the screws (3), lock washers (4) and nuts (5).
- 03** - Then, attach the right rear gang (6) to the left rear gang (7) by fixing using the screws (8), lock washers (9) and nuts (10).




▪ Assembly

• Assembly of the gangs in the main frame

After attaching the gangs, fix the frames to the main frames. For this, proceed as follows:

- 01** - Place the front (1) and rear (2) gangs in a flat, clean place.
- 02** - Then, place the main frame (3) on the front (1) and rear (2) gangs, fixing them through the screw (4), lock (5), lock washer (6) and nut (7).



OBSERVATION


Repeat the above procedure for the assembly of the gangs in the right central main frame.

▪ Assembly

• Assembly of the disc sections in the gangs

After fixing the gangs (1) on the main frame (2), fix the disc sections (3) for this, proceed as follows:

- 01** - Lift the front or rear of the disc harrow and place the disc section (3) in line and match the drilling of the shoes (4) with those of the bearings and make the fixation using the screws (5), flat washers (6), lock washers (7) and nuts (8).
- 02** - Then, lift the other part of the grid and repeat the operation, checking the concavity of the disks from one section to the other, which should be opposite.
- 03** - When finishing the Assembly, check that the shoes (4) were facing the concavity of the discs.



ATTENTION


When mounting the disc sections on the frames, note that the frame shoes should face the disc's concavity.

▪ Assembly

• Scrappers Assembly

After mounting the disk sections on the gangs, fix the wipers (1), to do this, proceed as follows:

- 01** - Place the scrappers (1) on the frames (2), fixing using the screws (3), plain washers (4), pressure washers (5) and nuts (6).



ATTENTION


When installing the cleaners, they should be 0.5 to 1.0 cm away from the discs.

▪ Assembly

• Wheel shaft support assembly

To mount the wheel shaft support (1), proceed as follows:

- 01** - Couple the wheel shaft (2), to the wheel shaft support (1) by fixing through the screws (3), lock washers (4) and nuts (5).




▪ Assembly

• Assembly of the wheel axle support in the main frame

After assembling the wheel shaft support, fix the wheel shaft support (1) to the main frame (2) for this, proceed as follows:

- 01** - Attach the wheel shaft support (1) to the main frame (2) fixing through the pins (3), lock washers (4) and nuts (5), as shown in detail "A".




▪ Assembly

• Wheels assembly

After assembling the wheel shaft support, fix the tires (1) for this, proceed as follows:

01 - Couple the tires (1) on the wheel shaft support (2) using the screws (3) and nuts (4).



ATTENTION


All tires must be mounted with anti-traction, that is, with the jaws facing the front of the GSPCR as shown in detail "A".

▪ Assembly

• Hitch drawbar assembly

To assembling the hitch drawbar, proceed as follows:

- 01** - Engage the hitch drawbar (1), on the main frames (2 and 3) fixing through the pins (4), flat washers (5), nuts (6) and cotter pins (7).
- 02** - Then, fix the support (8), through the screws (9) and nuts (10) and place the bushing (11) the rod (12), fixing with the pin (13), flat washer (14), cotter pin (15), plain washers (16) and nuts (17).
- 03** - Then, place the rod (18) and secure with the flat washers (19) and nuts (20).
- 04** - Finish by placing the nut (21) and the hose support (22).




▪ Assembly

• Hydraulic cylinder assembly on the hitch drawbar

To mount the hydraulic cylinder on the hitch drawbar, proceed as follows:

- 01** - Place the articulation support (1) on the crossbar (2) fixing with the pin (3), washer (4), castle nut (5) and cotter pin (6).
- 02** - Then, attach the base of the hydraulic cylinder (7) to the regulator (8) fixing through the pin (9), washer (10) and cotter pin (11).
- 03** - Then, attach the hydraulic cylinder rod (7) to the articulation support (1), fixing through the pin (12), pressure washer (13) and screw (14).




■ Assembly

• Hydraulic cylinder assembly on the main frames

To mount the hydraulic cylinders on the uprights, proceed as follows:

- 01 -** Couple the base of the hydraulic cylinder (1) at point "A", fixing through the pin (2), flat washer (3), cotter pin (4) and the hydraulic cylinder rod (1) at point "B", through the pin (5), plain washers (6), castle nut (7) and cotter pin (8).
- 02 -** Then, attach the hydraulic cylinder base (8) to point "C", fixing through the pin (9), flat washers (10), cotter pin (11) and the hydraulic cylinder rod (8) to point "D", through the pin (12), flat washer (13), castle nut (14) and cotter pin (15).




▪ Assembly

• Signpost assembly

To mount the signposts on the uprights, proceed as follows:

- 01** - Attach the sign plate (1) to the left central post (2) using the screws (3), plain washers (4), lock washers (5) and nuts (6).



ATTENTION

DO NOT work or transport the GSPCR mainly on highways without signposts.




OBSERVATION

Repeat the above procedure to mount the signpost on the right post.

■ Assembly

HYDRAULIC SYSTEM ASSEMBLY - GSPCR 28 / 32 / 36 DISCOS




▪ Hitch

DISC HARROW HITCH IN THE TRACTOR DRAWBAR

To couple the **GSPCR**, proceed as follows:

- 01** - Level the **GSPCR** coupling header (1) in relation to the tractor coupling through adjustments (2) of the coupling wheel. Then, slowly approach the harrow in reverse with the tractor, paying attention to the application of the brakes.
- 02** - Proceed with the coupling of the **GSPCR** to the tractor fixing it through the coupling pin (3), flat washer (4) and lock (5).
- 03** - Finally, attach the hoses (6) to the tractor's quick coupling.



IMPORTANT

When engaging the GSPCR, look for a safe and easily accessible place. Always use low gear with low acceleration.

▪ Leveling



DISC HARROW LEVELING - PART I

To level the **GSPCR**, proceed as follows:


01 - Place the tractor and **GSPCR** in a flat location.

02 - Then, before lifting the **GSPCR**, loosen the nuts (1) of the central rods (2) halfway through.


03 - Then, loosen the nuts and locknuts (3) of the header rods (4) leaving them at a distance of 20 mm from their face.



04 - Then, actuate to lift the grid and observe if the **GSPCR** is positioned in the front or rear:



GSPCR POSITIONED AT THE REAR



GSPCR POSITIONED AT THE FRONT


05 - Depending on the position of the **GSPCR**, make the following adjustments:

▪ Leveling

DISC HARROW LEVELING - PART II



06 - REAR POSITION:

With the **GSPCR** in this position, first lower it by relieving the hydraulic system. Then tighten the nuts and locknuts (5) of the header rods (6) every 10 mm. Then, activate the hydraulic system to lift the **GSPCR** and check its position. If you still need to adjust it, lower it again, tighten the nuts and locknuts (5) + 10 mm and again lift it up and check again. Repeat this procedure until the **GSPCR** is level.



07 - FRONT POSITION:

With the **GSPCR** in this position, first lower it by relieving the hydraulic system. Then, loosen the upper nuts (7) of the central bars (8) every 10 mm. Then, tighten the lower nuts (9) until they touch the face of the bushing (10). Then, activate the hydraulic system to lift the **GSPCR** and check its position. If you still need to adjust it, lower it again, loosen the upper nuts (7) + 10 mm and again lift it up and check again. Repeat this procedure until the **GSPCR** is level.



GSPCR LEVEL POSITION



ATTENTION


The measures mentioned in the leveling are initial parameters for leveling the GSPCR.

■ Regulations


• Regulation for transportation - Part I

Before transporting the **GSPCR**, proceed as follows:

- 01** - Sloosen the wing nuts (1) and remove the latches (2) from the upright (3).




- 02** - Then, fully activate the stroke of the hydraulic cylinders (4) of the wheel (5), place the locks (2) and secure them with the pins (6) and locks (7).




▪ Regulations

• Regulation for transportation - Part II

- 03** - Then, fully activate the stroke of the hydraulic cylinder (8) of the header, place the lock (9) and fix it with the pins (10) and locks (11).




- 04** - When the transport is finished, remove the locks (2) of the hydraulic cylinders (4) from the wheel (5) and fix them again on the main frame (3) using the wing nuts (1).



▪ Regulations

• Regulation for transportation - Part III

05 - Then, also remove the lock (9) of the hydraulic cylinder (8) from the drawbar.



ATTENTION


Do not transport the GSPCR without placing the locks (2) on the hydraulic cylinders (4) of the wheel (5) and on the hydraulic cylinder (8) of the header. Ignoring this warning could damage the hydraulic cylinders.

▪ Regulations

• Adjustment of disc harrow opening

To obtain the ideal penetration of the discs, the opening of the grid must be regulated, which varies according to the type of soil:

- **TERRAIN WITH GREATER DIFFICULTY OF PENETRATION:** The grid opening must be increased.
- **LIGHT AND LOOSE TERRAIN:** The grid opening must be decreased.



OPENS UP: Greater Depth.

DECREASES OPENING: Less Depth.

To increase or decrease the opening of the grid, proceed as follows:

- 01 - Loosen the nuts (1), lock washers (2), plain washers (3), remove the locks (4) and screws (5).
- 02 - Then adjust the frames (6) by decreasing or increasing their opening.
- 03 - Then, fix the frame (6) upstream again (7) using the screws (5), locks (4) flat washers (3), lock washers (2) and nuts (1).

! IMPORTANT


To start the work we recommend using a medium opening in the disc sections. If you need more penetration, increase the opening angle of the rear section.

The front section generally does not operate with a larger opening than the rear section.

The wheels also assist in disc depth control.

🔍 OBSERVATION

We advise you to control the working depth of the GSPCR by opening the disc sections and using the tires only in places where the GSPCR penetrates too much.




▪ Regulations

• Working depth adjustment - Part I

To adjust the working depth through the tires, the limiting rings (1) that are placed on the rods of the hydraulic cylinders are used, obtaining numerous working depth regulations. To adjust the working depth, proceed as follows:

- 01** - Remove the limiting rings (1) from the amount (2).
- 02** - Then, actuate the rods of the hydraulic cylinders (3) of the wheel until the necessary measure.
- 03** - Then, place the limiting rings (1) on the rods of the hydraulic cylinders (3) until the entire space between the coupling of the rod and the piston of the hydraulic cylinder (3) is filled.




ATTENTION

Always place the same number of limit rings (1) on the hydraulic cylinders (3) of the wheel.

▪ Regulations

• Working depth adjustment - Part II

01 - After finishing the work with **GSPCR**, remove the limiting rings (1) from the hydraulic cylinders (3) of the wheel and place them in the upright (2).



! IMPORTANT

After adjustment, GSPCR will always operate at the same depth, both in hard and loose terrain, this is because the limit rings (1) are limiting the travel of the hydraulic cylinder (3) of the wheel, that is, preventing the wheels from oscillating.

🔍 OBSERVATION


The limiting rings (1) that come with the GSPCR, have different sizes that, in combination, offer various depth regulations.

▪ Regulations

• Adjustment of disc harrow displacement - Part I

The displacement of the harrow must be done when the harrow is not giving a perfect finish, that is, leaving a trail of the tractor. For the harrow to work centrally with the tractor's traction line, proceed as follows:


- 01** - Remove the cotter pins (1), loosen the castle nuts (2), flat washers (3) and remove the screw (4).
- 02** - Then, move the coupling header (5) on the crossbar (6), making the ideal adjustment.
- 03** - Finish by fixing the screws (4), flat washers (3), castle nuts (2) and cotter pins (1).



▪ Regulations

• Adjustment of disc harrow displacement - Part II

Under normal working conditions and during transport, the coupling header (5) must remain in the central hole of the upper (7) and lower (8) plates. By changing the coupling header (5) to the other holes “A” and “B”, small lateral displacements of the **GSPCR** are obtained.



IMPORTANT

The GSPCR header and the tractor drawbar must be as aligned as possible with the working direction.
The tractor drawbar must remain loose during work and secure during transport.

▪ Operations

• Operating recommendations - Part I

The preparation of the **GSPCR** and the tractor will save you time in addition to a better result in field work. The following suggestions may be useful to you.

STRUCTURE

After the first day of work with the **GSPCR**, retighten all screws, nuts and check the condition of the pins and locks of the grid structure. Then perform a general tightening on all the screws and nuts of the grid structure every 24 hours of work.

DISC SECTIONS

Special attention to the **GSPCR** disc sections. Retighten all bolts and nuts on the disc sections daily during the first week of use. Then, retighten the bolts and nuts of the disk sections periodically.

GENERAL RECOMMENDATIONS

- 01** - Adjust the tractor according to the contents of the instruction manual, always using the front and rear weights to stabilize the equipment.
- 02** - Always do the coupling to the tractor at slow speed and with great care.
- 03** - When using the **GSPCR** it is important to check the coupling and cross leveling system to make sure that the discs will have the same depth of penetration into the ground.
- 04** - After coupling and leveling, the next Regulations will be made directly in the field of work, analyzing the terrain in its texture, humidity and the types of operations to be done with **GSPCR**.
- 05** - On the tractor, choose a gear that allows you to maintain a certain reserve of power, ensuring against unforeseen efforts.
- 06** - Observe the working and transport speeds specified on page 10. We do not recommend exceeding speeds to maintain service efficiency and avoid possible damage to the **GSPCR**.
- 07** - When executing maneuvers at the headlands, first activate the hydraulic cylinders gradually, lifting the disk sections.
- 08** - Do not disconnect any hoses without first relieving the pressure in the circuit. To do this, operate the control levers a few times with the engine off.
- 09** - Remove sticks or any other object that may get caught in the discs.

▪ Operations


• Operating recommendations - Part II

- 10** - In compacted terrain where disc penetration is difficult, the depth can be minimal, making work unsatisfactory. In these cases, the application of other more suitable products is recommended.
- 11** - During work or transportation, the tractor drawbar must remain fixed.
- 12** - When carrying out any maintenance on the **GSPCR**, it must be lowered to the ground and the engine turned off.
- 13** - **GSPCR** has several Regulations, however, only local conditions can determine the best regulation.

In case of doubt, never operate or handle GSPCR, consult the After Sales.
Telephone: 0800-152577 / E-mail: posvenda@baldan.com.br

• Direction of maneuvers

During harrowing (with the discs on the ground), DO NOT maneuver to the right, as the angles formed by the disc sections will transmit great effort to the equipment, especially the traction components.



ATTENTION

With the disk sections on the ground it is necessary to perform maneuvers on the left (closed side of the GSPCR) avoiding overloads.

■ Operations


• How to start harrowing

When starting the railing, one must always follow the terraces or contour cord, starting the operation in the sense that the terrace is always on the left side of the tractor.

🔍 OBSERVATION

Before starting operations with GSPCR, check it completely, retightening all screws, nuts, hose terminals, shafts and especially the disk sections.

• Harrow from the outside in




! IMPORTANT

Try to drive the tractor for good performance between GSPCR passes. Avoid forming non-harrowed tracks.

▪ Operations


• Harrow from the inside out

In this direction, greater perfection is obtained. When walking on headers too much, you may want to start another block.



• Blocks with contour lines

For terrains with contour line, it is usual to start with two blocks at a time, starting the work with the contour line on the left side of the tractor. When you reach the middle of the contour line, you may want to start another block to reduce fuel consumption.



▪ Calculations

• Approximate hourly production

To calculate the approximate hourly production of the **GSPCR**, use the following formula:

$$A = \frac{L \times V \times F}{X}$$

WHERE:

A = Area to be worked

L = Working width of the harrow (in meters)

V = Average speed of the tractor (in meters/hour)

F = Production factor: 0.90

X = Value of the hectare: 10,000 m²

Example: A GSPCR 28 disks, how much Ha it will produce in an hour of work at an average speed of 7 km / h.

A = ?

$$A = \frac{5,60 \times 7.000 \times 0,90}{10.000} = 3,52 \text{ Ha/h}$$

L = 5,60 m

V = 7.000 m/h

F = 0,90

X = 10.000 m² (Calculated in hectare)

Model	Nr of Discs	Working Width (mm)	Average Speed (m/h)	Production Factor	Approximate Production in Hectare Hour
GSPCR	28	5605	7.000	0,90	3,52
	32	6377	7.000	0,90	4,01
	36	7147	7.000	0,90	4,49

The formula for calculating the approximate production, refers to the calculation of areas to work or worked by **GSPCR**. If you want to know the time it will take to work an area of known value, just divide the value of this area by the hourly production of **GSPCR**.

Example: How much time “X” will it take for a 28-disk GSPCR grid to produce 35 hectares, at an average speed of 7km / h?

$$X = \frac{35 \text{ Ha}}{3,52 \text{ Ha/h}} = 9,94 \text{ hours approximately to work 35 hectares.}$$



The hourly production of the **GSPCR** can vary due to factors that change the rhythm of work such as (humidity and hardness of the soil, slope of the land, inadequate regulations and speed of work).


▪ Maintenance

The **GSPCR** was developed to provide you with the maximum return on land conditions. Experience has shown that periodic Maintenance of certain parts of the **GSPCR** is the best way to help you avoid problems, so we suggest checking.

• Tire pressure

The tires must always be correctly calibrated, avoiding premature wear due to excess or lack of pressure.

TYRE 400 X 60 14 PLY



USE: 52 LBS/POL²

ATTENTION

Never weld the tire-mounted wheel, heat can cause an increase in air pressure and cause the tire to explode.

When inflating the tire, position yourself next to the tire, never in front of it.

When inflating the tire, always use a containment device (inflation cage).

Assemble the tires with suitable equipment. The service should only be performed by people trained for the job.

IMPORTANT

When inflating tires, do not exceed the recommended inflation.

NOTE

The tire pressure of the tractor must be made according to the manufacturer's recommendation.

▪ Maintenance

GSPCR was developed to provide you with the maximum return on land conditions. Experience has shown that periodic Maintenance of certain parts of the **GSPCR** is the best way to help you avoid problems, so we suggest checking.

• Lubrication

Lubrication is essential for good performance and longer durability of **GSPCR** moving parts, contributing to savings in Maintenance costs.

Before starting the operation, carefully lubricate all grease fittings, always observing the lubrication intervals on the next page. Make sure the quality of the lubricant, as to its efficiency and purity, avoiding using products contaminated by water, earth and other agents.






• Greases and equivalents table

Manufacturer	Types of grease recommended
Petrobrás	Lubrax GMA-2
Atlantic	Litholine MP 2
Ipiranga	Ipiflex 2
Castrol	LM 2
Mobil	Grease MP
Texaco	Marfak 2
Shell	Alvania EP 2
Esso	Multi H
Bardahl	Maxlub APG-2EP
Valvoline	Palladium MP-2
Petronas	Tutela Jota MP 2 EP
	Tutela Alfa 2K
	Tutela KP 2K

 **ATTENTION** | If there are manufacturers and / or equivalent brands that are not listed in the table, consult the manufacturer's technical manual.

▪ Maintenance

- Lubricate every 24 hours of work



ATTENTION

When lubricating the GSPCR, do not exceed the amount of new grease. Enter a sufficient amount.

▪ Maintenance

• Disc section bearings adjustments


When the disc section bearings have gaps, proceed as follows to adjust them:

- 01** - Remove the washer (1).
- 02** - Then, loosen the screws (2) and remove the cover (3) from the bearing (4).
- 03** - Then, remove one or two gaskets (5) from the bearing cover (3) (4). Replace the cover (3) and retighten it.
- 04** - If the gap persists, you can face the cover (3) to increase the adjustment, then mount it on the bearing with as many joints as necessary.
- 05** - The bearing must rotate freely, that is, without looseness.



ATTENTION

Do not mount the bearing without the joints (5).



• Bearing oil

In the first days of work with **GSPCR**, check the oil level of the bearings daily, then check every 120 hours of work.

The oil change must be done every 1200 hours of work. Use 90 API GL4 transmission oil, MIL-L-2105; SAEJ306, May / 81: SAE 80W, 90 and 140.



ATTENTION

The ideal oil level is when it reaches the plug hole. To check the oil level of the bearing, look for a flat place.

▪ Maintenance

• Operational Maintenance

PROBLEMS	PROBABLE CAUSES	SOLUTIONS
Tires are damaged.	Work area with rocks, stubs or crop remains with stems that shred the tire.	Eliminate elements that damage tires before using the GSPCR.
	Improper tire pressure, creating deformations.	Maintain proper tires pressure.
Weird noise on wheels.	Loosen wheels or gap in wheel hub.	Retighten the wheel nuts and adjust wheel hub bearings.
	Breaking of bearings.	Identify the occurrence and females of the same type.
Quick coupling is not fitting.	Couplings of different types.	Change them for males and females of the same type.
Leakage in hydraulic hose.	Lack of sealing material on the thread.	Use sealing tape and retighten carefully.
	Insufficient tightening.	Retighten carefully.
	Damaged repairs.	Replace hubs.
Leakage in quick couplings.	Insufficient tightening.	Retighten carefully without excess.
	Damaged repairs.	Replace hubs.
Quick coupling is not coupling.	Couplings of different brands.	Use a quick coupling of the same brand.
	Mixing of needle-type coupling with sphere-type coupling.	Always use quick coupling of the same type.
	Pressure on the system.	Relief the pressure to couple.

▪ Maintenance

• Care

- 01** - Before each job, check the condition of all hoses, pins, bolts, bearings, discs and sections. Where necessary, retighten them.
- 02** - The displacement speed should be carefully controlled according to the land's conditions.
- 03** - The **GSPCR** is used in several applications, requiring knowledge and attention during handling.
- 04** - Only local conditions can determine the best method of operation of **GSPCR**.
- 05** - When assembling or dismantling any part of the **GSPCR**, employ appropriate methods and tools.
- 06** - Carefully observe the lubrication intervals in the various lubrication points of the **GSPCR**. Respect the lubrication intervals.
- 07** - Always check if the parts have wears. If there is a need for replacement, always demand Baldan original parts.
- 08** - Keep the **GSPCR** discs always sharp.



IMPORTANT

Proper and periodic maintenance are necessary to ensure the long life of **GSPCR**.

▪ Maintenance

• General cleaning

- 01** - When storing the **GSPCR**, make a general cleaning and wash it thoroughly with water only. Make sure the paint has not worn out, if it did, give a general coat, pass the protective oil and fully lubricate the **GSPCR**. Do not use burned oil or other abrasive.
- 02** - Fully lubricate the **GSPCR**. Check all moving parts of the **GSPCR** for wear and tear, make the necessary adjustment or replacement of the parts, leaving the harrow ready for the next job.
- 03** - After all maintenance work, store the harrow in a covered and dry place, properly supported.
 - Avoid: - That the discs come into direct contact with the ground.
 - The compression of the springs.
 - That the hydraulic hoses be properly capped.

▪ **Maintenance**

• **General cleaning**

- 04** - When connecting or disconnecting hydraulic hoses, do not let the terminals touch the ground. Before connecting the hydraulic hoses, wipe the connections with a clean, lint-free cloth. **Do not use tow!**
- 05** - Replace all adhesives, especially those about warnings, that are damaged or missing. Make everyone aware of the importance and risks of accidents when instructions are not followed.
- 06** - After all maintenance care, store your **GSPCR** on a flat, covered, dry surface, away from animals and children.
- 07** - We recommend washing the **GSPCR** with water only at the start of work.



ATTENTION

Do not use chemicals or abrasives to rinse the **GSPCR**, this may damage the paint and adhesives.

• **Conservation of the harrow - Part I**

To prolong the life and appearance of the **GSPCR** for longer, follow the instructions below:

- 01** - Wash and clean all harrow components during and at the end of the work season.
- 02** - Use neutral products to clean the harrow, following the safety and maintenance instructions provided by the manufacturer.
- 03** - Always carry out maintenance during the periods indicated in this manual.


• **Conservation of the harrow - Part II**

The practices and care below if adopted by the owner or operator make a difference to the conservation of the **GSPCR**.

- 01** - Be careful when performing high-pressure washing; do not direct the water jet directly into the connectors and electrical components. Isolate all electrical components;
- 02** - Use only NEUTRAL detergent and water (pH equal to 7);
- 03** - Apply the product, following the manufacturer's instructions strictly, on the wet surface and in the correct sequence, respecting the time of application and washing;
- 04** - Stains and dirt not removed with the products should be removed with the aid of a sponge.
- 05** - Rinse the machine with clean water to remove any chemical residues.

■ Maintenance

- 06 - Do not use:**
- Detergents with a basic active ingredient (pH greater than 7), can attack/stain the paint on the harrow.
 - **Detergents with acid active ingredient (pH less than 7), act as stripper/remover of zinc coating (the protection of parts against oxidation).**



- 07 -** Allow the machine to dry in the shade so that it does not accumulate water in its components. Very fast drying can cause stains on your paint.
- 08 -** After drying, lubricate all chains and greases according to the recommendations in the operator's manual.
- 09 -** Spray all the machine, especially the zinc parts, with protective oil, following the manufacturer's application guidelines. The protective also prevents dirt from adhering to the machine, facilitating subsequent washings.
- 10 -** Observe curing (absorption) time and application intervals as recommended by the manufacturer.

⚠ ATTENTION Do not use any other type of oil to protect the harrow (used hydraulic oil, "burnt" oil, diesel oil, castor oil, kerosene, etc.).

❗ IMPORTANT We recommend the following protective oils:


- Bardahl: Agro protective 200 or 300
- ITWChemical: Zoxol DW - Series 4000

🔍 OBSERVATION Ignoring the conservation measures mentioned above may result in the loss of warranty for painted or zinc-coated components which may exhibit oxidation (rust).

▪ Lifting

• Lifting points


GSPCR has several lifting points located in the uprights. When mounting or maintaining GSPCR, if you have to hoist with a winch, it is essential to engage the chains at the lifting points.



▪ Optional

• Cutting Disc

GSPCR can be optionally purchased with 32", 34" or 36".



NOTCHED DISC

■ Identification

• Nameplate

To consult the parts catalog or request technical assistance from Baldan, always indicate the model (01), serial number (02) and date of manufacture (03), which can be found on the identification plate of your **GSPCR**.

 BALDAN BALDAN IMPLEMENTOS AGRÍCOLAS S/A. AV. BALDAN, 1500 NOVA MATÃO CEP 15.993-900 MATÃO-SP BRASIL FONE: (16) 3221-6500 CNPJ: 52.311.347/0009-06 CREA/SP 0170977		
01 — Modelo / Model	Data / Date	
02 — N° de Série / Serial Number	Tipo / Type	
Capacidade / Load Capacity	Peso / Weight	



ATTENTION

The drawings contained in this Instruction Manual are for illustrative purposes.



CONTACT

In case of doubt, never operate or handle your equipment without consulting After Sales.

Phone: 0800-152577

e-mail: posvenda@baldan.com.br



PUBLICATIONS

Code: 53850104863 | CPT: GSPCR283600615



▪ Identification**• Product Identification**

Please make the correct identification of the data below, to always have information about the service life of your equipment.

Owner: _____

Dealer: _____

Property: _____

City: _____

State: _____

Certificate of Warranty no.: _____

Implement: _____

Serial No: _____

Purchase Date: _____

Invoice: _____

This image shows a blank sheet of white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.

■ Notes

[illegible]

BALDAN IMPLEMENTOS AGRÍCOLAS S/A ensures the dealer normal performance of the implement for a period of six (6) months as of the delivery date on the retail invoice to the first final consumer. During this period, **BALDAN** undertakes to repair defects in material and/or of manufacture of its liability, including labor, freight and other expenses of the dealer's liability.

In the warranty period, request and replacement of eventual defective parts shall be made to the dealer of the area, who will submit the faulty piece for **BALDAN** analysis. When this procedure is not possible and the resolving capacity of the dealer is exhausted, the dealer will request the support of **BALDAN Technical Assistance** through a specific form distributed to dealers. After analyzing the replaced items by Baldan Technical Assistance, and concluding that it is not a warranty, then the dealer will be responsible for the costs related to the replacement; as well as material expenses, travel including accommodation and meals, accessories, lubricant used and other expenses arising from the call out to Technical Assistance, and Baldan company is authorized to carry the respective invoice in the name of the resale. Any repair carried in the product within the dealer warranty deadline will only be authorized by **BALDAN** upon previous budget presentation describing parts and work to be performed.

The product is excluded from this term if it is repaired or modified by representatives not belonging to the **BALDAN** dealer network, as well as the application of non-genuine parts or components to the user's product. This warranty is void where it is found that the defect or damage is caused by improper use of the product, failure to follow instructions or inexperience of the operator.

It is agreed that this warranty does not cover tires, polyethylene tanks, cardan, hydraulic components, etc., which are equipment guaranteed by their manufacturers. Manufacturing and/or material defects, object of this warranty term, will not constitute, under any circumstances, grounds for termination of a purchase agreement, or for indemnification of any nature.

BALDAN reserves the right to change and/or perfect the technical characteristics of its products, without previous notice, and without obligation to proceed in the same way with the products previously manufactured.

▪ Inspection and Delivery Certificate

SERVICE BEFORE DELIVERY: This implement was carefully prepared by the sale organization, with all its parts inspected according to the manufacturing prescriptions.

DELIVERY SERVICE: The user was informed about the current warranty terms and instructed on the usage maintenance precautions.

I confirm that the user has been informed about the current warranty terms and instructed on the usage maintenance precautions.

Implement: _____ Serial Number: _____

Date: _____ Tax Number: _____

Dealer: _____

Telephone: _____ CEP: _____

City: _____ State: _____

Owner: _____

Telephone: _____

Address: _____ Number: _____

City: _____ State: _____

E-mail: _____

Sale date: _____

Signature / Dealer Stamp _____

1st copy - Owner

▪ Inspection and Delivery Certificate

SERVICE BEFORE DELIVERY: This implement was carefully prepared by the sale organization, with all its parts inspected according to the manufacturing prescriptions.

DELIVERY SERVICE: The user was informed about the current warranty terms and instructed on the usage maintenance precautions.

I confirm that the user has been informed about the current warranty terms and instructed on the usage maintenance precautions.

Implement: _____ Serial Number: _____

Date: _____ Tax Number: _____

Dealer: _____

Telephone: _____ CEP: _____

City: _____ State: _____

Owner: _____

Telephone: _____

Address: _____ Number: _____

City: _____ State: _____

E-mail: _____

Sale date: _____

Signature / Dealer Stamp _____

2nd copy - Dealer

▪ Inspection and Delivery Certificate

SERVICE BEFORE DELIVERY: This implement was carefully prepared by the sale organization, with all its parts inspected according to the manufacturing prescriptions.

DELIVERY SERVICE: The user was informed about the current warranty terms and instructed on the usage maintenance precautions.

I confirm that the user has been informed about the current warranty terms and instructed on the usage maintenance precautions.

Implement: _____ Serial Number: _____

Date: _____ Tax Number: _____

Dealer: _____

Telephone: _____ CEP: _____

City: _____ State: _____

Owner: _____

Telephone: _____

Address: _____ Number: _____

City: _____ State: _____

E-mail: _____

Sale date: _____

Signature / Dealer Stamp _____

3rd copy - Manufacturer (Please send completed within 15 days).

1.74.05.0059-5

AC MATÃO
ECT/DR/SP

RESPONSE CARD

NO STAMPING IS REQUIRED

THE STAMP WILL BE PAID BY:



BALDAN

BALDAN IMPLEMENTOS AGRÍCOLAS S/A.

Av. Baldan, 1500 | Nova Matão | CEP: 15993-900 | Matão-SP | Brasil

Tel: (16) 3221-6500 | Fax: (16) 3382-6500

www.baldan.com.br | email: sac@baldan.com.br

Export: Tel: +55 (16) 3221-6500 | Fax: +55 (16) 3382-4212 | 3382-2480

email: export@baldan.com.br



Avenida Baldan, 1500
Nova Matão
15.993-900
Matão/SP - Brasil
sac@baldan.com.br
export@baldan.com.br

+55 16 3221 6500
baldan.com.br